INDEX

Note to the Reader: Throughout this index **boldfaced** page numbers indicate primary discussions of a topic. *Italicized* page numbers indicate illustrations.

A

accessories, 318, *318*
Activate View command, 298–299
activating
  commands, 6
  views, 299, *299*
active views
  displaying, 7
  properties, 3
  visibility, 235
active worksets, 251
Add Edge tool, 44
Add Leader button, 274
Add Parameter option, 176
Add Points From Selected Layers dialog box, 321, *321*
Add/Remove Segments option, 78
Add Split Line option, 92
Add Vertical/Horizontal Segments option, railings, 136, *137*
Additional Copy Parameters settings, 248–249, *249*
Additional Settings option, views, 159
Additional Settings panel, 214
AECbytes website, 343
Align tool
  dimensions, 20, 22
  lights, 111
Aligned To Selected Levels option, 95
Aligned To Selected Views option, 26
Aligned tool, 17, 267
aligning
  copying, **26–28**, *27–28*
  dimensions, 17, 267
  elements, **20–22**, *20–22*
  lights, 111
  shafts, 95
  views on sheets, 295, *295*
  windows, 287
Alignment setting, 287
Angled Joins option, 136, *137*
Annotation Categories tab, 168
annotations and Annotate tab, **266**, *266*
  blocking, 259
  components, 149
  dimensions, 17, **267–270**, *267–270*
  families, **145–147**, *146–147*
  filled regions, 256–257
  groups, 265
  insulation, 264
  lines, 298
  regions, 254–255
  repeating details, 150, 261
  tags, 146, **271–273**, *271–273*
  text, **273–274**, *273*
Appearance tab
  schedules, 285, *285*
  walls, 56
Arc tool, 104
architects role in BIM workflow, **315**
Architectural annotations, 145, *146*
Area & Volume Computations dialog box, 334 *334*
Arrange panel, 261
arranging elements, **260–261**
Array tool, 25, 36
arrays
  creating, **25–26**, *26*
  options, 36, *36*

COPYRIGHTED MATERIAL

arrowheads for tags, 273, *273*
arrows, slope
  building pads, 321
  ceilings, 113, *113*
  floors, **90–91**, *90–91*
assigning
  elements to worksets, **236–238**, *236–238*
  materials, 56, *56*, 109, *109*
associating linked files, 249, 251
Attach Top/Base option, 67, *68*, 102
attached relationships with walls, 195
attaching walls
  to roof, **102**, *102*
  top and base, **67**, *67–68*
auditing files, **339**, *339*
AUGI (Autodesk User Group International), 343
Autodesk Seek panel, 144, *144*
automatic ceilings, **106–107**, *106–107*
automatic snapping, 8

B

background images, **30–32**, *31*
Baluster Offset option, 135
Baluster Placement option, 117
Baluster-Square option, 162
balusters
  editing, 117, *118*, 168, *168*
  level of detail, 160, 162–163
  settings, 135
Base Constraint parameter, 64
Base Is Attached parameter, 64
base masses, modeling, **39–41**, *40–41*
Base Offset setting
  ceilings, 109
  walls, 64, 109
baseboards, 259, *260*
basement floor plans, **294–300**, *295–300*
Basic Wall Generic - 6" option, 54, *54*
Basic Wall Node, 275
basic walls, **80–81**, *80–81*
batt insulation, 264
Begins With filter condition, 292
best practices, **334–338**, *335*, *337*
BIM (building information modeling) approach, 1
  overview, **309–313**, *310–313*
  project roles, **314–317**
  staffing, **314**
  team members, **317–318**
black color
  levels, 12, 35
  links, 304
  ramp lines, 125
  separation lines, 214
blocks, 36
  inserting and placing, 259, *259*
  title
    creating, **174–177**, *175–177*
    placing, **151**, *151*
  for toposurfaces, 320
blue color
  cut symbols, 301
  dimensions, 19, 50, 267, 269–270
  levels, 11–12, 35
  links, 304
  nodes, 204
  ramp lines, 125
  schedules, 301
  tags, 296–297
Bond Beam detail component, 148–149, *148*
Boolean queries, 292
borrowed elements
  central files, 238–239
  displaying, 244, *244*
borrowing elements, 249
boundaries
  building pads, 321
  ceilings, 110, *110*
  editing, 170–171
  filled regions, 256, *256*
  floors, 88, *89–90*
  ramps, **126–127**, *127*
  rooms, **213**, *213–214*
  schedules, 285
Boundary tool, 127

break lines
detail components, 149, *149*
editing, 170–171, *170–171*
stairs, 131, *132*
Break Symbol option, 131, *132*
breaking schedules, 302
Brick component, 261
brick and mortar components, 150
brick repeating detail, 172, *172*
Brick Standard component, 172
Bring Forward option, 261
Bring To Front option, 261, 263
Build panel, 154
Building Elevation view, 10
building information modeling (BIM) approach, 1
overview, **309–313**, *310–313*
project roles, **314–317**
staffing, **314**
teams members, **317–318**
building pads, **321–322**, *322*
bulkhead conditions, **109–110**, *110–111*
By Face tool, 93
By View tool, 342

C

CAD-based projects, 309, *310*, 314
CAD files
deleting and unloading, **333**
exploding, **333**
Calculate Totals option
mass floors, 49
schedules, 284–285
calculations
performing, **339–340**, *340*
volume, **334**, *334*
Callout tool, 256
Carriage Heights option, 133
case sensitivity of queries, 292
categories
families, 143–144, *144*, 164
schedules, **282–283**
Categories And Types To Copy list, 248
Ceiling tool, 106
ceilings, **105**, *106*
automatic, **106–107**, *106–107*
bulkhead conditions, **109–110**, *110–111*
changing, **112**, *112*
lights and grids, **111–112**, *112*
sketching, **107–109**, *107–109*
sloped, **113**, *113*, 340
cells, 36
central files, **232**
avoiding, 251
creating, **232**, *232*
saving to, **239–240**, *239–241*
CFD (computational fluid dynamics) model, 311
chain-select method, 14
chains of elements
lines, 59–60, *59–60*
selecting, 5, 14
walls, 97, *98*
chairs, placing, 24–26, *24–26*, 242, *243*
Choose Space Type and Color Scheme dialog box, *220*
circles for toposurfaces, 320
Circulation fill, 222
clipboard, copying to, 26
Clipboard panel, 26
Close Hidden option, 333
Close Hidden Windows tool, 333
closing
hidden windows, 13, 333
worksets, **244**, *244*, 251
CMU element, 172
Coarse detail level, 161–162
code requirements, architects for, 315
coffee table, 190, *190*
Collaborate tab
consultants, 247
synchronization, 239
workset access, 230
collections. *See* groups

color
  cut symbols, 301
  dashed lines, 34
  demolished walls, 201
  dimensions, 19, 50, 267–270
  levels, 11, 35
  lines, 175
  links, 304
  nodes, 204
  ramp lines, 125
  schedules, 301
  separation lines, 214
  tags, 296–297
Color field, 222
color fill plans, **220**
  legends, **220–224**, *220–225*
  sections, **225–226**, *225–227*
columns, **249–250**
commands, activating, 6
completed views, **205–206**, *205–207*
Component menu, 255
Component tool, 23
components
  detail. *See* details and detail levels
  families. *See* families
  hosted. *See* hosted components
  inserting, **255**
Compress option, 327
computational fluid dynamics (CFD) model, 311
computations
  performing, **339–340**, *340*
  volume, **334**, *334*
conflicts, errors and warnings for, 328
Constrain option, 24
constraints
  alignment, 22, *22*
  overconstraining, **336**
  walls, 15, *15*, 64
consultants, **247–250**, *248–249*
containers, worksets as, 250–251
content, team member additions for, 317
contour polylines for toposurfaces, 320
Copy/Monitor Options dialog box, 247–249, *247*
Copy/Monitor tool, 247–249
Copy tool
  groups, 187
  levels, 12, 35
Copy To Clipboard tool, 26
copying
  3D views, **342**
  aligned, **26–28**, *27–28*
  central files, 232
  fill patterns, 172
  groups, **187–188**, *187–188*, 241, *241*
  levels, 12, 35
  local files, 337
core worksets, 234
Corner Post baluster option, 135
corrupted files
  causes, 328
  fixing, **338–339**, *339*
Count field, 287
Create Detail Group dialog box, 37, *37*
Create Form tool, 40, 42
Create From Import option, 321
Create Group tool, 24, 185, 265
Create New Local option, 232
Create Similar tool, 187
Create Solid option, 43
crop regions, **335**
Crop tool, 5
crop windows and tags, 271, *272*
crossing railing lines, 128, *128*
Current Window option, 305
Curtain Grid tool, 71, *71*
curtain panel doors, **78–79**, *79*
curtain walls
  elevation profiles, **75**, *75*
  embedding, **74**, *74*
  grid lines, **71–73**, *71–73*, **76**, *76*
  masses for hosting, 51
  mullions, **72–73**, *73*, **76–77**, *76–77*
  panels, **77–78**, *78*
  selecting, 16
  types, **82**, *83*

curved curtain wall panels, **74**
cut symbols, 301
cutting wall openings, **68–69**, *69*

D

dashed lines for planes, 34
datums
  adjusting, **10–13**, *13*
  groups, 194
daylighting, 310
Deactivate View command, 300
deactivating views, 300, *300*
deadlines, 317
Default 3D View icon, 44, *44*
Default Wall material, 55
defaults
  3D view, 7
  ceilings, 106
  color assignments, 221
  handrails, 119
  insertion points, 186, *186*
  lines, 265
  mullions, 73
  names, 185
  railings, 115
  stair runs, 160, *160*
  templates, 31, 73, 145, *146*
  title blocks, 174
  wall placement, 17–18
Defines Origin option, 165
Defines Slope option, 99–102
deleting
  CAD files, **333**
  constraints, 64, 151
  hosts, 195
  levels, 152
  mullions, 76–77
  schedule rows, 286
  tags, 210
  wall openings, 69
Demolish tool, 200, *200*
demolition elements, **200–205**, *200–205*
depth, views, **335**
desks
  family level of detail, 162, *162*
  placing, **23–26**, *23–26*
Detach From Central option, 250
detaching wall top and base, **67**, *67–68*
Detail Component family, 262
Detail Component option, 255, 259
Detail Group menu, 265
Detail Level tool, 5, 335
Detail Line tool, 254, 260, 298
Detail Line toolset, 254, *254*
Detail rotation option, 262
details and detail levels, **253**, **323**
  annotating, **268**, *268*
  arranging elements in views, **260–261**
  components, **255**
  creating, **255–260**, *256–260*
  dimensions, **267–270**, *267–270*
  editing, **170–171**, *170–171*
  families, **148–149**, *148–149*
    display, **161–163**, *161–162*
    editing, **157–159**, *158–159*
  groups, **264–265**, *265*
  insulation, **264**, *264*
  legends, **274–276**, *275–276*
  linework
    description, **254**, *254*
    working with, **265–266**, *266*
  minimizing, **334–335**
  modeling decisions, **324**
  regions, **254–255**
  repeating
    creating, **261–264**, *261*, *263–264*
    description, **150**, *150*
    editing, **171–174**, *172–174*
    rules of thumb, 336
  scaling, **324**
  skills for, **324**
  tags, **271–273**, *271–273*
  team member additions for, 318
  text, **273–274**, *273–274*
Diagonal Crosshatch option, 173

dimensions
adding, **267–270**, *267–270*
aligning, 17, **20–22**, *20–22*, 267
curtain walls, 73
drafters for, 316
grid lines, 176, *176*
reference planes, 34, *34*
walls, **17–19**, *17–19*, 268, *268*
Disallow Join option, 204
display filters
phase, 196–198, *197–199*, 205–206
schedules
description, 283, *284*
Sheet List, 292, *293*
worksets, 237–238, *237*, **245–246**, *245–247*
dividing lines, 298, *298*
dividing models, **338**
Do Not Save The Project option, 240, *240*
Don't Copy This Type option, 248
Door tool, 23, 154
doors
curtain panel, **78–79**, *79*
demolition elements, 200–202
placing, 23, 154, *154*
in walls, 60, *60*
Doors And Windows setting, 20
drafters role in BIM workflow, **316–317**
drag and drop families, **342**
Draw panel, 7, *7*
arcs, 104
Pick Lines icon, 17, *17*
shapes, 254
slope arrows, 91
drawing sets
placing views, **294**
floor plans, **294–300**, *295–300*
schedules, **300–302**, *301–302*
printing documents, **302–306**, *303*, *305–306*
schedules. *See* schedules
Duplicate option, 55, *55*
duplicating
components, 242, *242*
groups, **189**, *189*
handrails, 116, *116*
walls, 55, *55*

E

edges
ceilings, 110, 112
masses, 44
views, 57, *57*, 303
Edit Assembly dialog box
ceilings, 109
walls, 55, *55*
Edit Baluster Placement dialog box, 117, *118*
Edit Boundary option, 170–171
ceilings, 110, 113
floors, 88
Edit Color Scheme dialog box, 221, *222*
Edit Extrusion tool
glazing, 180
hosted components, 179
Edit Family option, 163
level of detail, 161
title blocks, 175
Edit Group mode, 189–190, *190*, 265
Edit Group option, 27
Edit Group panel, 265, *265*
Edit In-Place button, 50
Edit Profile option
elevation, 75
wall profiles, 66–67
Edit Rails dialog box, 169, *169*
Edit Rails option, 117
Edit Scheme tool, 221
Edit Surface ribbon, 321
Edit Type option
detail, 257
dimensions, 268
filled regions, 173
railings, 117
repeating details, 263
stairs, 131
tags, 273
walls, 55

editing
ceiling boundaries, 110, *110*
ceilings, **112**, *112*
color legends, **222–224**, *222–225*
default color assignments, 221
details, **147–159**, *158–159*, **170–171**, *170–171*
families, **163**, *163*, **167**, *167*
floor boundaries, 88, *89–90*
groups, **26–28**, *27–28*, **189–191**, *189–191*
insertion points, **164–166**, *165–166*
rails, 117, 169, *169*
ramp boundary conditions, **126–127**, *127*
repeating details, **171–174**, *172–174*
shortcuts, 341, *341*
wall profiles, **66**, *66*
Element Properties option, 285
elements
aligning, **20–22**, *20–22*
arranging, **260–261**
assigning to worksets, **236–238**, *236–238*
borrowing, 238–239, 244, *244*
chains of
lines, 59–60, *59–60*
selecting, 5, 14
walls, 97, *98*
creating, **241–244**, *241–244*
demolition and proposed, **200–205**, *200–205*
types, **13–16**, *14–16*
wall, **60**, *60*
Elevation Of Poche Base settings, 323
elevations
BIM models, 310
curtain walls, **75**, *75*
datums for, 10–12
entering, 35, *35*
poches, 323
scales, 159, *159*
elevators, **340**, *340*
elliptical walls, **58**
embedding curtain walls, **74**, *74*
enabling worksharing, **230–231**, *230–231*
End Post baluster option, 135
EQ setting
dimensions, 19
grid lines, 176
profile lines, 168
reference planes, 179
equal signs (=) in formulas, 33
errors and warnings, **327–329**, *328–329*
Errors And Warnings dialog box, 327–328, *328*
Errors And Warnings tool, 327
Esc key, 19
exchanging groups, **191–192**, *192*
Existing phase, 195–196, 205
exploding imported CAD files, **333**
Export feature, 328
exporting
errors and warnings, 328, *328*
to gbXML, 334
Extend Below Base option, 131
Extend Rails To Meet option, 136, *137*
extensions, handrail, 124, *124*
Exterior - Brick and CMU on Mtl. Stud wall, 80
Exterior - Brick on Mtl. Stud wall, 80
Exterior Elevation view, 179
Exterior walls, 17
exterior worksets, 234
extruded roofs, **103–105**, *103–105*
Extrusion End setting, 104
extrusions, 41

F

face-based families
geometric contexts, 163
with multiple hosts, 155
overview, **152–153**, *153*
faces
floor area, 47
in-place masses, **44–45**, *45*
walls, **83–84**, *83*
families, **143**
annotations, **145–147**, *146–147*
categories and parameters, 164, *164*

detail components, **170–171**, *170–171*
detail level, **148–149**, *148–149*
display, **161–163**, *161–162*
editing, **157–159**, *158–159*
drag and drop, **342**
editing, **163**, *163*, **167**, *167*
face-based, **152–153**, *153*
hosted
editing, **177–181**, *178–181*
overview, **153–155**, *154*
insertion points, **164–166**, *165–166*
legends, 276
level-based, **151–152**, *152*
loading, **144–145**, *144–145*
origins, 165, *166*
parameters, 164
placing, **145**
profiles
associating, **147**, *147–148*
editing, **168–170**, *168–170*
purging, **325–326**, *326*
repeating details
description, **150**, *150*
editing, **171–174**, *172–174*
title blocks
description, **151**, *151*
editing, **174–177**, *175–177*
types, **143–144**, *143–144*
view display, **157–160**, *158–160*
window schedules, 287
Family Category And Parameters dialog box, 164, *164*
Family Editor
balusters, 162
component families, 183
desks, 165
hosted components, 178, *178*
profiles, 168
Family Element Visibility Settings dialog box, 161, *161*
Family Types dialog box, 180, *180*
fence posts, 172
fields and Fields tab
mass floors, 48, *48*
room keys, **218–219**, *218–219*
schedules
Sheet List, 291, *291*
windows, **287**, *287*
working with, **283**, *283*
File Open dialog box, 339
files
associating, 249
auditing, **339**, *339*
central, **232**
avoiding, 251
creating, **232**, *232*
saving to, **239–240**, *239–241*
corrupted
causes, 328
fixing, **338–339**, *339*
deleting and unloading, **333**
exploding, **333**
local
creating, **232–234**, *233*
saving, 233, *233*
purging, **336–337**, *337*
saving, **230–231**, *230–231*
size, **325**, 338
Fill available Space mode, 262
fill color, **220**
legends, **220–224**, *220–225*
sections, **225–226**, *225–227*
Fill Patterns dialog box, 173, *174*
Fill Patterns option, 172
Filled Region command, 173
filled regions
adding, 257
boundaries, 256, *256*
description, 255
Fillet Arc tool, 62
filling brick patterns, 172
Filter dialog box
walls, 9, *9*
worksets, 237, *237–238*

Filter tab
purpose, 283, *284*
Sheet List, 292, *293*
Filter tool, 237
filters
phase, 196–198, *197–199*, 205–206
schedules
description, 283, *284*
Sheet List, 292, *293*
wall selections, 9, *9*
worksets, 237–238, *237*, **245–246**, *245–247*
Fine detail level, 161
Finish Edit Mode button, 322
Finish Face setting, 20
Finish Mass tool, 46
Finish Sketch Mode option, 66
finishes
stairs, 132
walls, 290, *290*
Fixed Distance mode, 262
Fixed Number mode, 262
flashing, 260, *260*, 263
flexing window types, 181, *181*
Floor Area field, 49
Floor Plan option, 12
floor slabs, 256
Floor tool, 88, 98
floors
boundaries, 88, *89–90*
copying and monitoring, **250**
floor plans, **294–300**, *295–300*
mass
creating, **47**, *47*
scheduling, **48–50**, *48–50*
monitoring, 248, *248*
openings
with shafts, **95–97**, *96–97*
by sketching, **93–95**, *94–95*
sketching, **87–88**, *88*
sloped
creating, 129, *129*
shape editing for, **92**, *92–93*
sloped arrows, **90–91**, *90–91*
walls for, **97–98**, *98*
Floors tab, 248, *248*
fonts
schedules, 285
text, 132, 273
Formatting tab
mass floors, 49, *49*
schedules, 284–285, *285*, 289
formulas
calculations, **340**, *340*
errors and warnings, 328
height, 33, *33*
foundation walls, 322
Frame/Mullion Extrusion option, 179
frames, windows, 179, *180*
Function parameter
stairs, 131
walls, 17
furniture, overconstraining, 155
Furniture System Tag option, 146, *146*
Furniture tag, 167, *167*

G

G000 Cover Sheet, 300–302, *301–302*
gaps
floors, 90
railings, 128, *128*
window sill, 257
Generic - 12” floor type, 87
generic elements
designing, **56**
railings, **115–117**, *116–118*
walls, **53–57**, *54–57*
Generic Models tab, 153
Geographic information system (GIS) data, 311
geometric contexts, 163
geometry
errors and warnings, 328
imported, **336**
roofs, 104
Geometry panel, 104
geometry phases, **195–196**, *196*

GIS (geographic information system) data, 311
glazing
  BIM models, 310
  windows, 180, *181*
Google SketchUp tool, 315
Graphics tab, 56, *56*
grayed out views, 300
green dashed lines, 34
Grid Visibility parameter, 177
grids
  ceilings, **111–112**, *112*
  copying and monitoring, **249**
  curtain walls, **71–73**, *71–73*, **76**, *76*
  datums for, 10
  groups, 194
  rotating, **111–112**, *112*
  schedules, 285
  title blocks, **174–177**, *176–177*
gross floor area, 49–51, *50*
Group And Associate option, 25
Group Parameter Under option, 176
Group tool, 37, 244, *244*
groups
  best practices, **194–195**
  chairs, **24–26**, *24–26*
  copying, **187–188**, *187–188*, 241, *241*
  creating, **37–38**, *37–38*, **184–186**, *184–187*, 244, *244*
  defined, 36
  details, **264–265**, *265*
  duplicating, **189**, *189*
  editing, **26–28**, *27–28*, **189–191**, *189–191*
  exchanging, **191–192**, *192*
  and images, **39**
  loading, **193–194**, *193–194*
  overview, **183–184**
  purging, **325–326**, *326*
  replacing, 192
  saving, **192–193**, *193*
  schedules, 284, *284*, 287–288, *288*
grout, 262, *263*
GWB on Mtl. Stud Ceiling, 108, *108*
gypsum board
  ceilings, 109
  dimensions, 268
Gypsum Wall Board material, 109

H

Handrail - Design setting, 119, 123
handrails
  creating, 116–117
  profiles, 168–169, *169*
height
  ceilings, 113
  formulas, 33, *33*
  images, 32–33, *33*
  masses, 40, *41*
  railings, 129
  roofs, 100–101
  stair elements, 133
  stringers, *133*
  windows, 287
Height field
  images, 32–33, *33*
  window schedules, 287
Height Offset At Head setting
  ceilings, 113
  railings, 129
  roofs, 100–101
Height Offset At Tail setting
  ceilings, 113
  railings, 129
  roofs, 101
help, resources for, **343**
Hidden Line mode, 303
hidden lines, **303–304**
hidden windows, 12–13
Hide Crop Boundaries option, 304
Hide ref/Work planes option, 304
Hide Scope Boxes option, 304
Hide Unreferenced View tags option, 304
Highlight In Model feature, 286

Home tab
ceilings, 106
color legends, 220
datums, 11
doors, 23, 60, 154
families, 164–165
fill patterns, 173
floors, 87, 93
levels, 35
lines, 175
masking regions, 258
railings, 128–130
ramps, 124
reference planes, 34
roofs, 103
room tags, 210
shafts, 340
stairs, 118, 120–121
volume computation, 334
walls, 7, 17, 54, *54*
Host Length option, 276
hosted components
editing, **177–181**, *178–181*
geometric contexts, 163
groups, 183, 194–195
legends, 276
overview, **153–155**, *154*
railings, **122–124**, *123–124*, **130**, *130*
wall elements, **60**, *60*
hyphens (-) in names, 250

I

Image Placement tool, 31
images
background, **30–32**, *31*
and groups, **39**
scaling, **32–33**, *32–33*
Import Panel, 31, *31*
imported data
exploding, **333**
geometry, **336**
toposurfaces from, **319–321**, *320–321*
importing background images, **30–32**, *31*
In-Place Editor panel, 46
in-place masses, **39**, 50
3D, **44–46**, *44–46*
bass, **39–41**, *40–41*
middle, **41–42**, *42–43*
upper, **43–44**, *43*
In-Place Masses tool, 39
Include Elements In Linked Files option, 283
Individual Owners option, 245–246, *246*
inserting and Insert tab
blocking, 259, *259*
CAD files, 333
components, **255**
curtain panel doors, 78
families, 144
groups, 194, *194*
images, 31, *31*
lights, 111
links, 320
insertion points
families, **164–166**, *165–166*
groups, 186, *186–187*
Inside option for repeating details, 262
instance parameters, **64–65**, *65*
insulation, **264**, *264*
Insulation tool, 264
interface, **1–2**
Options Bar, **6**, *6*
Project Browser, **4–5**, *4*
Properties palette, **2–4**, *3–4*
status bar, **5**, *5*
View Control Bar, **5**, *5*
ViewCube, **5**, *6*
workflow, **6**
datums, **10–13**, *13*
layout, **7–8**, *7–8*
modifying tools, **8–10**, *9–11*
Interior - Partition walls, 17
interior worksets, 234, 244, *244*
iPad, 29–30, *30*
iPhone, 29
isolating walls, 238
Itemize Every Instance option, 284, 291, *292*

J

Jenkins model, 328, *329*
Johnson, Luke, 343
Join tool, 46
Join/Unjoin Roof option, 104
joined roofs, 104–105, *105*
joining masses, **46**
joins, railings, 136, *137*

K

Key Name field, 217
keyboard shortcuts, 341, *341*
Keyboard Shortcuts dialog box, 341, *341*
keynote legends, 274
keynoting, drafters for, 316
keys, rooms, **216–220**, *217–220*
Khemlani, Lachmi, 343

L

L Shaped Handrail profile family, 168–169
labeling, **273–274**, *273–274*
Landing Height Adjustment setting, 135–136, *135–136*
landings
  exercises, 139–140, *139*
  settings, 135–136, *135–136*
  straight run with, **119–120**, *120*
layouts
  creating, **7**–8, *7–8*
  repeating details, **262**
leaders
  tags, 272, *272*
  text, 274
left and right options vs. mirroring, 195
Legend Components settings, 275–276, *275*
Legend tool, 220, 226, 274–275
legends
  adding, **274–276**, *275–276*
  color, **220–224**, *220–225*
length
  hosts, 276
  walls, 63, *63*
level of detail in families
  modifying, **161–163**, *161–162*
  overview, **157–159**, *158–159*
level railings, **128–130**, *128–130*
Level tool
  sketches, 35
  stairs, 121
levels
  building pads, 321
  constraints, **151–152**, *152*
  datums for, 10–12
  groups, 194
  sketches, **34–36**, *34–36*
  stairs, 121, *121*
  worksharing, **249**
libraries for categories, 144
lights, ceilings, **111–112**, *112*
Line Color option, 175
Line Style option, 258
Line Style panel, 254
Line Styles option, 214
Line Styles Type Selector panel, 265
Line tool
  blocking, 258
  title blocks, 175
linear paths for repeating details, 150, *150*
lines
  blocking, 258
  detail, **254**, *254*
  grid. *See* grids
  hidden, **303–304**
  railings, 128, *128*
  ramps, 125
  separation, **214**, *215–216*
  split, 92, *92*
  title blocks, 175
  views, 298, *298*
  walls, 59–60, *60*
Lines tool, 258

linework
description, **254**, *254*
working with, **265–266**, *266*
Linework tool, 265–266
linked files, associating, 249, 251
links, 304
Load As Group option, 194
Load Families button, 255
Load Family option, 78, 111, 144, 165
Load From Library panel, 78, 144, 194
Load Into Project button, 259
loading
families, **144–145**, *144–145*
groups, **193–194**, *193–194*
local copies
limiting, **337**
saving, 233, *233*
local files, **232–234**, *233*
Location Line parameter, 64
Location Line to Finish Face setting, 17
Lock 3D View tool, 5
lock symbol, 19
locking
alignment, 22
dimensions, 19, *19*

M

Main Baluster Pattern option, 135
Make Plan View option, 11
Manage tab
aligning elements, 20
demolition elements, 200
errors and warnings, 327, 338
fill patterns, 172
printing, 303
purges, 325–326, 336
room separation lines, 214
title blocks, 175
views, 159
Masking Region tool, 257–258
masking regions, 255, 257–258, *258*
masonry, 80, *80*, 261
mass floors
creating, **47**, *47*
scheduling, **48–50**, *48–50*
Mass Floors tool, 47
masses, 29
in-place, **39**, 50
3D, **44–46**, *44–46*
bass, **39–41**, *40–41*
middle, **41–42**, *42–43*
upper, **43–44**, *43*
joining, **46**
massing studies, **50–51**, *50–51*
sketching, **41**
Massing & Site tab, 39, 321–323
Material Tag button, 271–272
Material tags, 271–272, *272*
materials
stairs, 132
takeoff schedules, 280–281
walls, 56, *56*
math, **339–340**, *340*
Maximum Incline Length setting, 134
Maximum Spacing mode, 262
Measure tool, 32
measuring imported images, 32, *32*
Medium detail level, 161
memory requirements
determining, **332**
imported geometry, 336
metal decking, 261
middle mass modeling, **41–42**, *42–43*
Mirror - Pick Axis tool, 9
mirroring
limitations, 195
process, 8–**10**, *10*
Mode palette, 170
Model Groups tab, 189
Model Line tool, 58, *58*
Model Site panel, 323
modelers in BIM workflow, **316**

modeling
in-place masses, **39**, 50
3D, **44–46**, *44–46*
bass, **39–41**, *40–41*
middle, **41–42**, *42–43*
upper, **43–44**, *43*
sites, **318–319**, *318*
building pads, **321–322**, *322*
toposurfaces, **319–321**, *319–321*
models, dividing, **338**
Modify panel, 254
Modify tab, 3
aligning elements, 20
elevations, 12
groups, 37
joins, 46
levels, 35
linework, 265
mirroring, 9–10
railings, 123
splitting, 70
modifying tools, 8–**10**, *9–11*, **16**
aligned copying and group editing, **26–28**, *27–28*
aligning elements, **20–22**, *20–22*
dimensions, **17–19**, *17–19*
rotating, grouping, and arraying, **23–26**, *23–26*
modifying walls, **63**, *63–64*
Monitor command, 249
Monolithic stair family, 115, 131
mouse, zooming and panning with, 12
Move Down option, 287
Move To option, 36
Move Up option, 287
moving
grid lines, 73, *73*
ribbon, 343
view tags, **296–297**, *297*
walls, 213, *213*, 224
Mullion tool, 72, *73*
mullions
adding, **72–73**, *73*
unpinning and toggling, **76–77**, *76–77*
Multi-Category schedules, 282
Multiple option, 24
multistory shafts, 95–97, *96–97*
multistory stair runs, **121–122**, *121–122*
Multistory Top Level setting, 121
multiuser workflow. *See* worksharing

N

Name dialog box, 39, *40*
Name field, 217
names
groups, 185, *186*
handrails, 116, *116*
in-place masses, 39, *40*
levels, 12
room keys, 217–218, *218*
types, 242, *242*
Navigation bar, 14, 158
nesting groups, 194
New Legend View dialog box, 275, *275*
New option for room keys, 218
New Only option, 173
New Schedule dialog box, 281–282, *281*
mass floors, 48
settings, 286, 289
New Schedule menu, 217
New Sheet dialog box, 292, *293*
New Sheet option, 294
New Subcategory dialog box, 175
No Connector option, 136, *137*
Nosing Profiles, 132
nosings, 132, *132*
Note Block schedules, 281
number of views reductions, **327**

O

Object Styles dialog box, 175, *175*
offsets, baluster, 135
Opaque/Transparent setting, 268
Open In Group Editor, 185

opening
projects, 7
worksets, **244**, *244*, 251
openings
floors
with shafts, **95–97**, *96–97*
by sketching, **93–95**, *94–95*
walls, **68–69**, *69*
operating systems, **332**
optimizing performance, **331–334**, *334*
Options Bar, **6**, *6*
Options pane for printing, **304–305**
Orient To View option, 341
orientation of families, 157
origin of families, 165, *166*
overconstraining
furniture, 155
problems from, **336**
overlapping lines for railings, 128, *128*
overlapping masses, **46**
Overwrite The Existing Version option, 166
ownership status, 245–246, *246*

P

panning with mouse, 12
Parameter Properties dialog box, 176, *176*
parameters
detail components, 149
railings, **134–138**, *134–138*
ramps, **134**
reference planes, 179
stairs, **130–133**, *131–133*
title blocks, 176, *176*
walls, **64–65**, *65*
parametric models, 310
parapet caps, 147, *148*
parking spaces, 318
Paste Aligned command, 26, *27*
Paste tool, 95
performance, optimizing, **331–334**, *334*
perspectives in BIM models, 310
Phase Created properties, 195
Phase Demolished properties, 195–196
phasing, 183, **195**
completed views, **205–206**, *205–207*
demolition and proposed elements, **200–205**, *200–205*
geometry, **195–196**, *196*
views, **196–198**, *197–199*
Phasing panel, 200, *200*
Pick Lines mode, 17, *17*
Pick Lines tool, 17, 59, *59*
Pick New Host tool, 124, 130
Pick Wall tool, 98
picking walls, **58–59**, *58–59*
pinned mullions, 77
Place A Component option, 165
Place Component menu, 165
Place Component tab, 152
Place Detail Component tab, 255
Place Detail Group button, 265
Place Detail Lines menu, 298
Place Lines tab, 175
Place On Face option, 152
Placement panel, 152
placing
blocking, 259, *259*
desks and chairs, 23–26, *23–26*, 242, *243*
families, **145**
title blocks, **151**, *151*
views on sheets, **294**
floor plans, **294–300**, *295–300*
schedules, **300–302**, *301–302*
windows, 154, *154*
Plan Views option, 12
plans in BIM models, 310
poches, quick cut, **342**, *342*
polylines for toposurfaces, 320
predictability in BIM models, 311, 313
preloaded annotations, 145, *146*
preloaded profiles, 147, *147*
Previous + New option, 198
Print command, 302

Print dialog box, **302–303**
hidden lines, **303–304**, *304*
Options pane, **304–305**
Print Range, **305–306**, *306*
Print Range setting, 302, **305–306**, *306*
Print Setup dialog box, 304–306, *306*
Printer control panel, 303
Product Information heading, 331
profiles
elevation, **75**, *75*
families
associating, **147**, *147–148*
editing, **168–170**, *168–170*
walls, **66–68**, *66*
Project Browser, **4–5**, *4*
project roles in BIM workflow, **314–317**
project templates, 145
projects, opening, 7
Properties palette, **2–4**, *3–4*
balusters, 162
building pads, 322
constraints, 15
crop windows, 271
dimensions, 32–33, 88, 268
families, 164
filled patterns, 172
grids, 176–177, *177*
groups, 265
levels, 11
offsets, 17
railings, 134, 170, *170*
ramps, 134
regions, 257
repeated detail, 263
selected walls, 14, *14*
slopes, 102
stairs, 121, 131
tags, 273
Type Selector, 7, 16
View Control Bar, 5
walls, 13–14, *14*, 70, 99
windows, 181
worksets, 236–237
proposed elements, **200–205**, *200–205*
Proposed phase, 195–198
Purge Unused dialog box, 326, *326*, 336–337, *337*
Purge Unused tool, 325–326, 336
purging
families and groups, **325–326**, *326*
files, **336–337**, *337*

Q

QAT. *See* Quick Access toolbar (QAT)
quality control, **325**
errors and warnings, **327–329**, *328–329*
file size, **325**
purging unused families and groups, **325–326**, *326*
rules of thumb, 336
views, **327**
Quick Access toolbar (QAT), 7
3D views, 44
dimensions, 267
hidden windows, 12–13
measurements, 32
section tools, 130
quick cut poches, **342**, *342*

R

Rail Structure option, 135, 169
Railing tool, 116, 123, 130
railings
generic, **115–117**, *116–118*
host function, **122–124**, *123–124*, **130**, *130*
level and sloped conditions, **128–130**, *128–130*
parameters, **134–138**, *134–138*
profiles, 168–169, *169*
tools, 139
Railings Type option, 119
RAM requirements
determining, **332**
imported geometry, 336
Ramp Max Slope setting, 134

Ramp tool, 124
ramps, **124–125**
  boundary conditions, **126–127**, *127*
  parameters, **134**
  straight runs, **125–126**, *125–126*
raster processing, 304
Rectangle tool, 40
Rectangular Handrail family, 168
red color for demolished walls, 201
Ref Plane tool, 34
reference planes
  creating, 37–38, *38*
  datums for, 10
  hosted components, 179, *179*
  sketches, **34–36**, *34–36*
regions, **254–255**
  filled
    adding, 257
    boundaries, 256, *256*
    description, 255
  masking, 257–258, *258*
Relinquish All Mine option, 239
relinquishing elements and worksets, 239–240, *240–241*
Reload option for groups, 193
Reload Latest option, 239
renaming
  handrails, 116, *116*
  types, 242, *242*
Render Appearance tab, 56
Rendered setting for walls, 57
Rendering Show/Hide tool, 5
Repeating Detail command, 263
Repeating Detail Component tool, 261, 263
repeating details
  creating, **261–264**, *261*, *263–264*
  description, **150**, *150*
  editing, **171–174**, *172–174*
  rules of thumb, 336
repetitive relationships, 183
replacing groups, 192
Reset Profile option, 68
resetting wall profiles, **66**, *66*, **68**
resources, Revit, **343**
Reveal Hidden Elements tool, 5
Revit Help menu, 343
Revit Professionals, 343
RevitCity site, 145, *145*, 343
ribbon, 1, 343
right and left options vs. mirroring, 195
Risers option, 132, *133*
Roof By Extrusion command, 103
Roof By Footprint option, 99
Roof tool, 99
roofs
  extruded, **103–105**, *103–105*
  masses for hosting, 51
  walls for, **99–103**, *100–103*
Room & Area palette, 210
Room & Area panel, 61, *61*
Room Bounding parameter, 65
Room function, 61, *61*
Room Separation Line option, 210, 214
Room Tag option, 226
Room Tag With Area option, 61, 212, *212*
Room tool, 210
rooms
  boundaries, **213**, *213–214*
  color fill plans, **220**
    legends, **220–224**, *220–225*
    sections, **225–226**, *225–227*
  keys, **216–220**, *217–220*
  schedules, **288–290**, *289–290*
  separation lines, **214**, *215–216*
  tags, **209–212**, *210–212*
  and walls, 61–62, *61–62*
Rotate tool, 23, 25, *25*, 28, *28*, 112
rotating, **23–26**, *23–26*, **111–112**, *112*
.rvt extension, 193, *193*

S

Sand - Dense fill pattern, 173
Save Group option, 192, *193*

saving
to central file, **239–240**, *239–241*
files, **230–231**, *230–231*
groups, **192–193**, *193*
local copies, 233, *233*
print settings, 305
Scale tool, 5
scales and scaling
detailing, **324**
elevation, 159, *159*
families, 157
images, **32–33**, *32–33*
rules of thumb, 336
stair runs, 160, *160*
Schedule Keys option, 217
Schedule Properties dialog box, 218, *218*
Appearance tab, **285**, *285*
buttons, **286**, *286*
Fields tab, **283**, *283*
Filter tab, **284**, *285*
Formatting tab, **284–285**, *286*
mass floors, 48–49, *48–49*
rooms, 289–290
Sorting/Grouping tab, **284**, *284*
windows, 287–288, *287–288*
Schedule/Quantity button, 286
Schedule/Quantity schedules, 280–281
Schedule tab
buttons, 286, *286*
room fields, 219
schedules, **279**
adding to sheets, **300–302**, *301–302*
BIM models, 310
breaking, 302
categories, **282–283**
drafters for, 316
errors and warnings, 328
family categories for, 143, *143*
mass floors, **48–50**, *48–50*
rooms, **288–290**, *289–290*
Sheet List, **290–294**, *291–294*
types, **280–281**, *281*
windows, **286–288**, *287–288*
Schedules menu, 217
schematic design, **29**
drafters for, 317
in-place masses, **39**
3D, **44–46**, *44–46*
bass, **39–41**, *40–41*
middle, **41–42**, *42–43*
upper, **43–44**, *43*
mass floors, **47–50**, *47–50*
massing studies, **50–51**, *50–51*
sketches. *See* sketches
section boxes, 27, *27*
Section Cut Material option, 323
Section tool, 130
sections
BIM models, 310
stairs, 130–131
tags and fill colors in, **225–226**, *225–227*
Select All Instances option, 333
Select Import Instance option, 321
Select Items To Copy dialog box, 172, *173*
Select Levels dialog box, 27, *27*
Selected Views/Sheets option, **305**
Send Backward option, 261
Send To Back option, 261
separation lines, **214**, *215–216*
series of walls, **61**, *61*
Set Host function, 126
7 Max Riser 11" Tread stair family, 115
Shaded mode, 303
Shaded With Edges mode, 57, *57*, 303
Shading setting, 56–57
Shadows tool, 5
Shaft tool
elevators, 340
floors, 95
shafts
elevators, 340
floors openings with, **95–97**, *96–97*
shape editing for sloped floors, **92**, *92–93*
Shape Editing tools, 92
shape handles
editing, 92, *93*
walls, 63, *64*
Sheet Composition panel, 151

Sheet icon, 151
Sheet List Properties dialog box, 291–293, *291–293*
Sheet List schedules, 281, **290–294**, *291–294*
Sheet Name, sorting by, 284
Sheet Number, sorting by, 284
sheetrock, 256
sheets
  drafters for, 316–317
  placing views on, **294**
    floor plans, **294–300**, *295–300*
    schedules, **300–302**, *301–302*
shortcuts, keyboard, 341, *341*
Show All option, 198
Show Camera option, 342
Show Categories From All Disciplines option, 282
Show Complete option, 206, *206–207*
Show/Hide Crop tool, 5
Show Mass option, 39
Show New option, 198, *199*, 205
Show Previous + Demo option, 206
Show Previous Phase option, 198, *198*
shrubs, 318, *318*
Simplify Surface button, 321
site modeling, **318–319**, *318*
    building pads, **321–322**, *322*
    toposurfaces, **319–321**, *319–321*
Site Settings dialog box, 323, *323*
64-bit OS, **332**
size
  files, **325**, 338
  schedule text, 285
Sketch mode for roofs, 100
SketchBook Pro tool, 29–30, *30*
sketches, **29–30**, *30*
  background images, **30–32**, *31*
  ceilings, **107–109**, *107–109*
  floors
    creating, **87–88**, *88*
    openings, **93–95**, *94–95*
  groups, **37–38**, *37–38*
  masses, **41**
  reference planes and levels, **34–36**, *34–36*
  scaling images, **32–33**, *32–33*
  walls, **57**, *58*
Slope Arrow tool, 91, 129
slope arrows
  building pads, 321
  ceilings, 113, *113*
  floors, **90–91**, *90–91*, 129
sloped ceilings, **113**, *113*, 340
sloped floors
  creating, 129, *129*
  shape editing for, **92**, *92–93*
sloped railings, **128–130**, *128–130*
sloped roofs, **99–103**, *100–103*
snapping, 8
solar gain in BIM models, 311
Sort By setting, 49
Sorting/Grouping tab
  mass floors, 49
  schedules
    creating, **287–289**, *288*
    settings, **284**, *284*
    Sheet List, 291, *292*
Sound Transmission Class (STC), 274–275
spacing
  repeated details, 262
  walls, **60–62**, *61–62*
Spacing option, 262
Specialty Equipment option, 164
Split Element tool, 70, *70*, 202, *202*
split lines, 92, *92*
splitting walls, **69–70**, *69–70*, 202–203, *203–204*
stacked walls, **82**, *82*
staffing BIM projects, **314**
Stair Carriages option, 133
stairs, **115**
  balusters
    editing, 117, *118*, 168, *168*
    level of detail, 160, 162–163
    settings, 135
  exercises, 139–140, *139*
  level of detail, 162
  multistory runs, **121–122**, *121–122*
  parameters, **130–133**, *131–133*

railings
generic, **115–117**, *116–118*
host function, **122–124**, *123–124*
scaling, 160, *160*
straight run, **118–119**, *118–119*
straight run with landing, **119–120**, *120*
tools, 139
Stairs tool, 118, 120
Start Post baluster option, 135
status, ownership, 245, *246*
status bar, **5**, *5*
Storefront curtain walls, 74
straight run ramps, **125–126**, *125–126*
straight run stairs, **118–119**, *118–119*
straight run with landing stairs, **119–120**, *120*
Stringer Height option, 133, *133*
stringers, stairs, 133, *133*
strings, dimension, 267
subscription support, 343
Sun Path tool, 5
swapping walls, **70**, *71*
SWC (Synchronize With Central), 325
Switch Windows command, 12–13, *13*
Synchronize And Modify Settings option, 239
Synchronize Now option, 239
Synchronize panel, 239
Synchronize With Central (SWC), 325
Synchronize With Central dialog box, 239, *239*
System Requirements option, 331

T

Tab key for wall references, 18, *18*
tables
coffee, 190, *190*
placing, 242, *243*
Tag All Not Tagged dialog box, 226, *226*
Tag All Not Tagged option, 226
Tag By Category option, 146, 271
Tag On Placement button, 23
Tag panel, 146
tags
adding, **271–273**, *271–273*
annotations, **145–147**, *146–147*
rooms, 61–62, *62*, **209–212**, *210–212*
sections, **225–226**, *225–227*
text in, 296
Tangent Arc tool, 127
tangent arcs
creating, 57
ramps, 127
Tangent Joins option, 136
teams, BIM, **317–318**
templates, project, 145
Temporary Dimension Properties, 20, *20*
temporary dimensions
curtain walls, 73
setting, 20, *20–21*
Temporary Hide/Isolate tool, 5
text
adding, **273–274**, *273–274*
dimensions, **267–270**, *267–270*
schedules, 285
stairs, 132
tags, 296
Text Font options, 132
Text palette, 273
Text Size options, 132
Text tab, 273
Text tool, 273
thickness of building pads, 321
3 GB switch, **332**
3D views, 7
3D Cutaway, 27, *27*
copying, **342**
in-place masses, **44–46**, *44–46*
30 Degree Arrow option, 273
32-bit OS, **332**
tiled windows, **14–15**, *14–15*
title blocks
creating, **174–177**, *175–177*
placing, **151**, *151*
toggling mullions, **76–77**, *77*
top and base of walls, **67**, *67–68*

Top Constraint parameter
roof, 99
walls, 15, *15*, 65
Top Is Attached parameter, 65
Top Offset setting, 95
toposurfaces
descriptions, **318–319**, *318–319*
from imported data, **319–321**, *320–321*
Transfer Project Standards tool, 172, 303
transparent backgrounds for dimensions, 269
Treads option, 132, *132*
trees, 318, *318*
Trim tool, 8
Trim/Extend To Corner tool, 10, *11*
trimmed railings, 138, *138*
2D annotations, 151
Type field, 287
Type Mark field, 287
Type Properties dialog box
dimensions, 268
grids, 177, *177*
names, 242, *242*
railings, 117, 169
ramps, 134, *134*
regions, 257
repeating details, 261, *261*, 263
stairs, 131, *131*
walls, 55
Type Selector, 3–4
blocking, 259
ceilings, 108
details, 255
lights, 111
walls, 16

U

Unconnected Height parameter, 65, 109
underscores (_) in names, 250
ungrouping groups, 194
Unjoin Walls option, 16
unloading unused CAD files, **333**
unpinning mullions, **76–77**, *77*
unreferenced view tags, 304
unused families and groups, **325–326**, *326*
unused files, **336–337**, *337*
Updates option, 245
updating
color legends, 223–224, *223–225*
massing studies, **50–51**, *50–51*
room keys, 220, *220*
upper mass modeling, **43–44**, *43*
User Interface tab, 341

V

vector processing, 304
vehicles, 318
vertices for in-place masses, 45, *45*
View Control Bar, **5**, *5*
View Links in Blue option, 304
View List schedules, 281
View option, 276
View Phase setting, 196
View/Sheet Set dialog box, 306, *306*
ViewCube, **5**, *6*
floor plans, 110
Orient To View, 341
rotating, 45
views and View tab, 2, *2*
activating, 299, *299*
arranging elements in, **260–261**
completed, **205–206**, *205–207*
deactivating, 300, *300*
depth, **335**
displaying, 7
drafters for, 316–317
families, **157–160**, *158–160*
hidden views, 333
hidden windows, 13
legends, 274–276
limiting, **327**
lines, 298, *298*
managing, **332–335**
mass floors, 48
phases, **196–198**, *197–199*

placing on sheets, **294**
floor plans, **294–300**, *295–300*
schedules, **300–302**, *301–302*
Plan Views, 12
properties, 3
vs. reference levels, 35, *35*
room keys, 217
schedules, 280, 286, 289, 291
tags, **296–297**, *297*
tiled windows, 15
title blocks, 151
visibility, 235
visibility and Visibility/Graphic Overrides dialog box
balusters, 162
elevators, **340**, *340*
family parameters, 168
family profiles, 165, *165*
grids, 176
hosted components, 178, *178*
layers, 333
print ranges, 305
shortcuts, 341
worksets, **235**, *235*, 238, *238*, 246, *246*
Visibility Setting column, 235
Visible portion Of Current Window option, 305
Visual Style tool, 5
volume computation, **334**, *334*

W

Wall Centerlines setting, 17
Wall Opening option, 68
wall studs, 261
Wall tool, 7, 17, 20, 54, *54*, 57, 62
walls
attached relationships with, 195
basic, **80–81**, *80–81*
chain-select method, 14
constraints, 15, *15*, 64
copying and monitoring, **250**
curtain. *See* curtain walls
demolition elements, 200–203
dimensions, **17–19**, *17–19*, 268, *268*
elliptical, **58**
faces for, **83–84**, *83*
finishes, 290, *290*
for floors, **97–98**, *98*
foundation, 322
generic, **53–57**, *54–57*
height, 100
hosting elements, **60**, *60*
instance parameters, **64–65**, *65*
isolating, 238
legends, 274–276, *275–276*
masses for hosting, 51
modifying, **63**, *63–64*
moving, 213, *213*, 224
openings, **68–69**, *69*
picking, **58–59**, *58–59*
placing, **7–8**, *8*, 17
profiles, **66–68**, *66*
for roofs, **99–103**, *100–103*
shape handles, 63, *64*
sketching, **57**, *58*
spaces, **60–62**, *61–62*
splitting, **69–70**, *69–70*, 202–203, *203–204*
stacked, **82**, *82*
swapping, **70**, *71*
top and base, **67**, *67–68*
type changes, 16, *16*
Walls tab
openings, 68
profiles, 66, 68
worksharing, 248
warnings
ceilings, 107
finding, **327–329**, *328–329*
level deletions, 152
reviewing, **338**
tags, 271, *271*
welded railings, 138, *138*
Wide Lines option, 298
width settings
family profiles, 168
insulation, 264
window schedules, 287

window sill
creating, **256–260**, *256–260*
dimensions, 267, 269, *269*
repeating details, 263, *264*
Window tags, 271–272, *272*
windows
frames, 179, *180*
glazing, 180, *181*
placing, 154, *154*
schedules
adding to sheets, **300–302**, *301–302*
creating, **286–288**, *287–288*
tiled, **14–15**, *14–15*
in walls, 60, *60*
Wireframe button, 41
Wireframe mode, 303
wireframes, 41–42, *42*
Work Plane panel, 34, *34*
workflow
BIM, 309
overview, **309–313**, *310–313*
project roles, **314–317**
staffing, **314**
team members, **317–318**
interface, **6**
datums, **10–13**, *13*
layout, **7–8**, *7–8*
modifying tools, **8–10**, *9–11*
working views, 327
Workset Assignments tab, 246
worksets and Worksets dialog box
adding, **234**, *234*
assigning elements to, **236–238**, *236–238*
borrowed elements, 245
as containers, 250–251
display filters, **245–246**, *245–247*
opening and closing, **244**, *244*, 251
ownership status, 245, *246*
settings, 231, *231*
visibility, **235**
Worksets option, 245
Worksets palette, 230
workshared files, **337–338**
worksharing, **229**
central files, **232**
avoiding, 251
creating, **232**, *232*
saving to, **239–240**, *239–241*
consultants, **247–250**, *248–249*
display setting, 245–246, *246*
elements, **241–244**, *241–244*
enabling, **230–231**, *230–231*
guidelines, **250–251**
local files
creating, **232–234**, *233*
saving, 233, *233*
saving to central file, **239–240**, *239–241*
worksets. *See* worksets and Worksets dialog box
Worksharing dialog box, 231, *231*
Worksharing Display Off option, 245
Worksharing Display Setting dialog box, 246, *246*

Y

YouTube, 343

Z

zero error requirements, 328
Zoom All To Fit option, 14, *14*
Zoom Sheet Size option, 158, *158*
Zoom To Fit option, 158, *158*
zooming with mouse, 12